



ULTIMATE BACKYARD BACKSTOP

ASSEMBLY GUIDE

1. The base consists of the four pole segments with the larger diameter. Assemble the four poles together, making sure the spring-loaded buttons click into place.
2. The side poles consist of the four pole segments with the smaller diameter. Each side pole consists of two individual pole segments. The upper pole segments have a T-shaped metal fitting at their top ends and the lower pole segments have a smooth metal sheath at their top ends. Insert the bottom ends of the upper pole segments into the metal sheaths of the lower poles.
3. Insert the assembled side poles into the vertical angled fittings on both sides of the assembled base. Make sure they are fully and securely inserted as the net will cause tension on these poles.
4. Make sure the net is oriented so the velcro flaps are at the bottom and slide the side pockets of the net down over each side pole, one at a time.
5. Connect the four corners of the net to the two upper T-shaped side pole caps as well as the two lower hooks on the base.
6. Finish securing the net by wrapping the three velcro straps around the base.
7. Secure the fabric STRIKEZONE panel in the desired placement on the net by using the velcro tabs found on each of its four corners.

